




HARMONY RAIL PLANTER

Planting Instructions

Self-Watering Rail Planter with inside separator and overflow protection (for outdoor use)

STEP 1
OUTDOOR USE ONLY



Carefully punch out (with a hammer and a flat screwdriver) or drill a 3/8" - 9,5mm hole in the **2 cavities** at the bottom of the planter (marked: "Punch out X for drainage").

WARNINGS

- To avoid damage to inside separator, do not punch out or drill too deep.
- Do not punch out or drill outside the cavities. This will eliminate the water reservoir.
- **DO NOT PUNCH OUT FOR INDOOR USE.**

STEP 2
OUTDOOR AND INDOOR USES



Place plant in the planter.

ADDITIONAL INFORMATION

• When planter is pierced for drainage (OUTDOOR USE ONLY), the excess water from rain or overwatering will escape (overflow protection).

• Water when surface of soil feels dry or according to plants' needs.

• Add fertilizer according to plants' needs.

STEP 3
OUTDOOR AND INDOOR USES



Fill planter with a high quality potting soil and plant material to approximately 1" - 2,5cm from top.


VOLUME CHART OF WATER RESERVOIR AND SOIL

SIZE
27" - 69cm

WATER
108 oz (US) - 3,2L

SOIL
6.2 gal (US) - 23,6L

STEP 4
OUTDOOR AND INDOOR USES



Dampen with water.



Will fit a 2"x4" or 2"x6" railing.